



TECHNICAL MANUAL

WE
PROVIDE
SCAFFOLDING
GLOBALLY.

Building the Future.

CORONET 2024

TABLE OF CONTENTS



1. Presentation	01-04
2. Specification	05-07
3. Materials	08
4. Loading capacity of components	09-64
5. Security Instructions	65-68
6. Assembly Process	69-85
7. Anchoring and Diagonal brace	86-88
8. Typical solutions	89-90
9. Maintenance	91
10. Applicable Regulations	92-93



1. PRESENTATION



This manual provides the necessary instructions for the correct assembly and safety use Coronet Ringlock/Multidirectional Scaffold System.



The company that hires the scaffolding has the responsibility to inform the workers that they are going to use such scaffolding from the information contained in this "Technical Manual". They must also make sure that the users who mount or use the towers are formed in accordance with current regulations.

■ Brief introduction of Coronet Group

Since its inception in the scaffolding business, the 'Coronet®' brand has stood for quality. With nearly two decades of successful operation, Coronet has emerged as the world's largest exporter of scaffolding to the North American market over the past years (2019-2022), as per the latest publicly available custom data.

Coronet USA serves as the American division of the Coronet Scaffolding Group. Our corporate offices are based in Suzhou, China, while our American operations are directed from offices in Houston, TX, New Orleans, LA, and Concepcion, Chile.

As a leading player in the scaffolding industry, we prioritize the well-being and happiness of our employees, whom we consider the cornerstone of our success. With values centered on 'customer first,' 'integrity,' and 'team cooperation,' Coronet stands out as an active, innovative, and passionate company. We extend our gratitude to all those who have placed their trust in Coronet over the years, and we welcome new customers to join us in our journey.

■ Automated Production

Coronet® scaffolding has larger supply chain, with more than \$ 100 million annual capacity.

We focus on automated scaffold production, starting with the Phase I, semi-automatic welding machines and steel deck shaping systems. Until now, it includes fully automatic hot-dip galvanizing plant, welding and packaging assembly line.

We continue to adopt highly-automated manufacturing to meet high quality and quick delivery requirements.




■ Coronet Ringlock System

The Coronet ringlock scaffold system uses the highest quality steel and our products are finished and protected by hot-dipped zinc galvanizing. This method of finishing maximizes the utilization and extends the product life.


All coronet components are stamped with traceability marks.

Batch number: XXCSYYZZ

XX=Serial Number CS= Coronet Scaffold YY=Month of Manufacture ZZ= Year of Manufacture



The following diagram represents the most common Ringlock components used. Most Scaffold structure are made from these basic components yet the Ringlock system comes with a variety of accessories for all your scaffolding requirements.



The elements that make up the supporting structure of the system, mostly tubular profiles, generally have the following measurements:

Outside Diameter: 48.3 mm

Wall thickness 3.2 mm

Steel Grade: Q355 High Tensile Strength Steel or Q235 Steel

All comply with American, Canadian, Europe, Australian, and OSHA standards.



2. SPECIFICATION



■ Definition and use

The Ringlock system is a modular scaffold made up of elements Standard, Ledger and Diagonal brace that are connected to each other forming a rigid structure. The connection is a knot or rosette made up of a disk with 8 positions, located at a distance of 0.50 meters on the verticals.

Coronet ringlock scaffolding systems allow the Ledger of scaffolding to be used in diagonal or multi-angle combinations to facilitate their application on different building facades.

These systems are especially used in the construction industry, building maintenance, power generation, chemical processing, oil refining, aviation, shipbuilding and other industrial fields.

The Coronet ringlock scaffolding system is manufactured with high-strength steels and automatic welding processes. This ensures that the stability of the scaffolding is higher than that of common products.

■ Technical data

Modular connection by knot or rosette

The connection to the standard load-bearing element of various components of the Coronet ringlock scaffolding system is made by means of a specially shaped knot or rosette, welded every 0.50 m on the standards, in combination with the ends of the Ledger pieces, which have a wedge that must be embedded or inserted in the different holes of the rosette.

Flat rosette has four narrow holes and four large holes once the wedge is well secured, the four narrow holes fix the ledger automatically and firmly at the correct angles. Four large holes allow alignment of ledgers and diagonal braces at the required angle.




Welding details of rosette in vertical direction




Finished Products in Package

Once the wedge is well secured, the four narrow holes fix the ledger automatically and firmly at the correct angles. Four large holes allow alignment of ledgers and diagonal braces at the required angle.




Connection of ledger elements with the rosette.

- Slide the end of the ledger that carries the wedge over the flat rosette.
- Insert the wedge into one of the holes.
- Fix the wedge with a metal hammer until the impact rebounds.



The connection becomes a force-transmitting rigid connection that can immediately carry loads in all directions.





3. MATERIALS



We only use the highest quality steel in our products. Our steel is certified and tested in Element and MTS laboratories respectively and it conforms to or exceeds industry standards no matter the location or climate.

Steel Grade	Q355B
Lab.	Element Materials Technology
Test Method	ASTM A370
Yield Strength	63750psi (440Mpa)
Tensile Strength	75525psi (521Mpa)
Elongation	22%

Element Laboratory (United States) Testing Report:



Coronet Scaffold Group Suzhou Co., Ltd.
SIFC SIP, Suzhou City
Jiangsu Province, China
P: +86-512-85557000 / F: +86-512-85557111

Element Materials Technology
222 Cavalcade Street
Houston, TX
77009-3213 USA

P 713 692 9151
F 713 696 6307
T 888 786 7555
info.houston@element.com
element.com

TEST CERTIFICATE — EAR-CONTROLLED DATA

Date: 01/15/2013
P.O. No.: EH00006255Q/0
W/O No.: COR006-12-12-09683-3

RING-LOCK SYSTEM

TENSILE TEST RESULTS

Specifications: n/a
Test Method: ASTM A370

Direction: Longitudinal / Full Section

Specimen Identification	Dimensions OD x Wall Thk. (in.)	Total Load (lbs)	Yield Strength (psi)	Ultimate Tensile Strength (psi)
1	1.928 x 0.130	56,100	64,000	76,400
2	1.923 x 0.130	55,300	64,000	76,500
3	1.923 x 0.130	54,500	65,000	74,400
4	1.926 x 0.130	54,800	62,000	74,800

4. LOADING CAPACITY OF COMPONENTS

In our Coronet Ringlock Scaffolding system, we achieve the highest levels of stability and robustness, based on the great load capacity of the components that form it, together with the optimal union system by means of a knot or rosette defined above.

3 TIER RINGLOCK SYSTEM TOWER

Laboratory & Standard:

ANSI/SSFI SC100-5/05, Element Materials Technology Laboratory in Huston, United States

Part No.: 3 Meter Vertical RV910, 5' Horizontal RH50, 7' Horizontal RH70

Test Method: ANSI/SSFI SC100-5/05

Set#	Max Load	Load Per Leg	Load per Leg at 4:1 Safety Factor	Deviation from Average
	[LBS]	[LBS]	[LBS]	%
1	85,210	21,300	5,330	7%
2	74,390	18,600	4,650	6%
3	78,830	19,710	4,930	1%
Average	79,475	19,870	4,965	/



Coronet Scaffold Group Suzhou Co., Ltd.
 SIFC SIP, Suzhou City
 Jiangsu Province, China
 P: +86-512-85557000 / F: +86-512-85557111

Element Materials Technology
 222 Cavalcade Street
 Houston, TX
 77009-3213 USA

P 713 692 9151
 F 713 696 6307
 T 888 786 7555
 info.houston@element.com
 element.com

TEST CERTIFICATE – EAR-CONTROLLED DATA

Date: 01/15/2013
 P.O. No.: EHO0006255Q/0
 W/O No.: COR006-12-12-09683-1

Sample Information: 3 Tier Ring System Shoring
Part No.: 3 Meter Vertical RV910, 5' Horizontal RH50, 7' Horizontal RH70

LOAD TEST RESULTS 3 TIER RING SYSTEM TOWER

Load Method: ANSI/SSFI SC100-5/05

Set #	Max Load (lbs)	Load (lbs) per Leg	Load (lbs) per Leg at 4:1 Safety Factor	Deviation from Average (%)
1	85,210	21,300	5,330	7%
2	74,390	18,600	4,650	6%
3	78,830	19,710	4,930	1%
Average:	79,475	19,870	4,965	---



Representative view of system setup



Typical deflection of leg at failure

This document contains technical data whose export and re-export/retransfer is subject to control by the U.S. Department of Commerce under the Export Administration Act and the Export Administration Regulations. The Department of Commerce's prior written approval may be required for the export or re-export/retransfer of such technical data to any foreign person, foreign entity or foreign organization whether in the United States or abroad.

■ AXIAL LOAD TEST RESULTS

Laboratory & Standard:

ANSI/SSFI SC100-5/05, Element Materials Technology Laboratory in Huston, United States

Part No.: RV910 Verticals with RH50 and RH70 Horizontals

Test Method: ANSI/SSFI SC100-5/05

A ledger was connected to the rosette, and the ledger was pulled at a 90 degree angle away from the vertical leg to create an axial loading test on the rosette and ledger head connection.



Coronet Scaffold Group Suzhou Co., Ltd.
SIFC SIP, Suzhou City
Jiangsu Province, China
P: +86-512-85557000 / F: +86-512-85557111

Element Materials Technology
222 Cavalcade Street
Houston, TX
77009-3213 USA
P 713 692 9151
F 713 696 6307
T 888 786 7555
info.houston@element.com
element.com

TEST CERTIFICATE – EAR-CONTROLLED DATA

Date: 01/15/2013
P.O. No.: EHO0006255Q/0
W/O No.: COR006-12-12-09683-3

RING-LOCK SYSTEM

Using RV910 Verticals with RH50 and RH70 Horizontals

AXIAL LOAD TEST RESULTS


A ledger was connected to the rosette, and the ledger was pulled at a 90 degree angle away from the vertical leg to create an axial loading test on the rosette and ledger head connection.

Specimen Identification	Dimensions OD x Wall Thk. (in.)	Total Load (lbs)	Failure
1	1.923 x 0.130	15,110	Rosette
2	1.923 x 0.130	16,830	Rosette
3	1.923 x 0.130	16,520	Rosette



RINGLOCK VERRTICAL / STANDARD


Ringlock Vertical (Standard) with spigot has rosettes at 500mm interval, Tube size: OD48.3x3.2mm, Steel Grade: Q355 High Tensile Strength Steel. Surface treatment: Hot dip galvanized.



Item No.	Ref. No	Description	Height		Weight		Safety Load
			Meters	Feet	Kgs	Lbs	Lbs
RV99	RL0264	6 Ring Standard 3.0m w/ spigot	3.0	9'-9"	14.56	32.07	4,965
RV82	RL0182	5 Ring Standard 2.5m w/ spigot	12.26	8'-2"	12.26	27.00	5,525
RV66	RL0218	4 Ring Standard 2.0m w/ spigot	9.95	6'-6"	9.95	21.92	5,983
RV411	RL0096	3 Ring Standard 1.5m w/ spigot	7.65	4'-11"	7.65	16.85	9,450
RV33	RL0084	2 Ring Standard 1.0m w/ spigot	5.34	3'-3"	5.34	12.10	12,350
RV18	RL0010	1 Ring Standard 0.5m w/ spigot	3.04	1'-8"	3.04	6.70	13,900

LEDGER

Ringlock Ledger, Tube size: OD48.3x3.2mm, Steel Grade: Q355 High Tensile Strength Steel. Surface treatment: Hot dip galvanized. Shorter Ledgers are used as horizontal support for Ringlock Planks. Ledgers are also typically used as mid rail and top guard rails.



Item No.	Ref. No	Description	Height		Weight		Point Load	Uniform Load
			Meters	Feet	Kgs	Lbs		
RH10	RL0120	1' Ledger 305mm	0.305	1'	1.86	4.10	3,350	6,700
RH20	RL0633	2' Ledger 610mm	0.61	2'	2.94	6.48	2,920	5,500
RH22	RL0681	2'-2" Ledger 650mm	0.65	2'-2"	3.08	6.78	2,270	4,500
RH25	RL1482	2'-5" Ledger 732mm	0.732	2'-5"	3.37	7.42	2,200	4,500
RH210	RL1509	2'-10" Ledger 880mm	0.88	2'-10"	3.90	8.59	2,000	4,100
RH30	RL0268	3' Ledger 914mm	0.91	3'	4.02	8.85	1,980	4,000
RH36	RL0621	3'-6" Ledger 1065mm	1.065	3'-6"	4.56	10.04	1,390	3,100
RH37	RL1483	3'-7" Ledger 1090mm	1.09	3'-7"	4.65	10.24	1,350	3,000
RH310	RL0680	3'-10" Ledger 1150mm	1.15	3'-10"	4.86	10.70	1,300	2,380
RH40	RL1461	4'-0" Ledger 1220mm	1.22	4'	5.11	11.26	1,200	1,860
RH43	RL1484	4'-3" Ledger 1286mm	1.28	4'-3"	5.34	11.76	1,105	1,650
RH50	RL0620	5'-0" Ledger 1520mm	1.52	5'-0"	6.19	13.63	874	1,300
RH52	RL0679	5'-2" Ledger 1572mm	1.57	5'-2"	6.36	14.01	845	1,275
RH54	RL1384	5'-4" Ledger 1625mm	1.625	5'-4"	6.55	14.43	778	1,210
RH60	RL1479	6'-0" Ledger 1828mm	1.82	6'	7.27	16.01	663	1,170
RH69	RL1503	6'-9" Ledger 2072mm	2.072	6'-9"	8.13	17.91	475	1,118
RH70	RL1434	7'-0" Ledger 2130mm	2.13	7'	8.34	18.37	450	1,070
RH80	RL0349	8'-0" Ledger 2440mm	2.44	8'	9.44	20.79	430	1,065
RH86	RL1485	8'-6" Ledger 2572mm	2.572	8'-6"	9.91	21.83	412	1,057
RH90	RL1510	9'-0" Ledger 2743mm	2.743	9'	10.52	23.17	380	1,048
RH100	RL0636	10'-0" Ledger 3050mm	3.05	10'	11.61	25.57	350	1,040



Coronet Scaffold Group Suzhou Co., Ltd.
SIFC SIP, Suzhou City
Jiangsu Province, China
P: +86-512-85557000 / F: +86-512-85557111

Element Materials Technology
222 Cavalcade Street
Houston, TX
77009-3213 USA
P 713 692 9151
F 713 696 6307
T 888 786 7555
info.houston@element.com
element.com

TEST CERTIFICATE – EAR-CONTROLLED DATA

Date: 01/15/2013
P.O. No.: EHO0006255Q/0
W/O No.: COR006-12-12-09683-2

Sample Information: Ringlock Horizontal 5'
Part No.: RH50

LEDGER LOAD TESTING
Test Method: ANSI/SSFI SC 100-5/05**Point Load**

Sample #	Max Load (lbs)	Load at 4:1 Safety Factor (lbs)	% Deviation From Average
1	3,497	874	0
2	3,497	874	0
3	3,497	874	0
Average	3,497	874	---



Point Load Test Setup



Typical Deflection at Maximum Load



Coronet Scaffold Group Suzhou Co., Ltd.
SIFC SIP, Suzhou City
Jiangsu Province, China
P: +86-512-85557000 / F: +86-512-85557111

Element Materials Technology
222 Cavalcade Street
Houston, TX
77009-3213 USA
P 713 692 9151
F 713 696 6307
T 888 786 7555
info.houston@element.com
element.com

TEST CERTIFICATE – EAR-CONTROLLED DATA


Date: 01/15/2013
P.O. No.: EHO0006255Q/0
W/O No.: COR006-12-12-09683-2

Sample Information: Ringlock Horizontal 7'
Part No.: RH70

LEDGER LOAD TESTING
Test Method: ANSI/SSFI SC 100-5/05

Point Load

Sample #	Max Load (lbs)	Load at 4:1 Safety Factor (lbs)	% Deviation From Average
1	1,790	450	1
2	1,770	440	3
3	1,860	460	3
Average	1,810	450	---



Point Load Test Setup



Typical Deflection at Maximum Load



Coronet Scaffold Group Suzhou Co., Ltd.
SIFC SIP, Suzhou City
Jiangsu Province, China
P: +86-512-85557000 / F: +86-512-85557111

Element Materials Technology
222 Cavalcade Street
Houston, TX
77009-3213 USA
P 713 692 9151
F 713 696 6307
T 888 786 7555
info.houston@element.com
element.com

TEST CERTIFICATE – EAR-CONTROLLED DATA

Date: 01/15/2013
P.O. No.: EHO0006255Q/0
W/O No.: COR006-12-12-09683-2

Sample Information: Ringlock Horizontal 10'
Part No.: RH100

LEDGER LOAD TESTING
Test Method: ANSI/SSFI SC 100-5/05**Point Load**

Sample #	Max Load (lbs)	Load at 4:1 Safety Factor (lbs)	% Deviation From Average
1	1,370	340	1
2	1,390	350	1
3	1,390	350	1
Average	1,380	350	---



Point Load Test Setup



Typical Deflection at Maximum Load



Coronet Scaffold Group Suzhou Co., Ltd.
SIFC SIP, Suzhou City
Jiangsu Province, China
P: +86-512-85557000 / F: +86-512-85557111

Element Materials Technology
222 Cavalcade Street
Houston, TX
77009-3213 USA
P 713 692 9151
F 713 696 6307
T 888 786 7555
info.houston@element.com
element.com

TEST CERTIFICATE – EAR-CONTROLLED DATA


Date: 01/15/2013
P.O. No.: EHO0006255Q/0
W/O No.: COR006-12-12-09683-2

Sample Information: Ringlock Horizontal 5'
Part No.: RH50

LEDGER LOAD TESTING
Test Method: ANSI/SSFI SC 100-5/05

Uniform Distributed Load

Sample #	Max Load (lbs)	Load at 4:1 Safety Factor (lbs)	% Deviation From Average
1	5,230	1,310	1
2	5,330	1,330	3
3	5,030	1,260	4
Average	5,190	1,300	---



Distributed Load Test Setup



Typical Deflection at Maximum Load



Coronet Scaffold Group Suzhou Co., Ltd.
SIFC SIP, Suzhou City
Jiangsu Province, China
P: +86-512-85557000 / F: +86-512-85557111

Element Materials Technology
222 Cavalcade Street
Houston, TX
77009-3213 USA
P 713 692 9151
F 713 696 6307
T 888 786 7555
info.houston@element.com
element.com

TEST CERTIFICATE – EAR-CONTROLLED DATA

Date: 01/15/2013
P.O. No.: EHO0006255Q/0
W/O No.: COR006-12-12-09683-2

Sample Information: Ringlock Horizontal 7'
Part No.: RH70


LEDGER LOAD TESTING
Test Method: ANSI/SSFI SC 100-5/05

Uniform Distributed Load

Sample #	Max Load (lbs)	Load at 4:1 Safety Factor (lbs)	% Deviation From Average
1	4,020	1,010	7
2	4,420	1,110	3
3	4,420	1,110	3
Average	4,290	1,070	---



Distributed Load Test Setup



Typical Deflection at Maximum Load



Coronet Scaffold Group Suzhou Co., Ltd.
SIFC SIP, Suzhou City
Jiangsu Province, China
P: +86-512-85557000 / F: +86-512-85557111

Element Materials Technology
222 Cavalcade Street
Houston, TX
77009-3213 USA
P 713 692 9151
F 713 696 6307
T 888 786 7555
info.houston@element.com
element.com

TEST CERTIFICATE – EAR-CONTROLLED DATA

Date: 01/15/2013
P.O. No.: EHO0006255Q/0
W/O No.: COR006-12-12-09683-2

Sample Information: Ringlock Horizontal 10'
Part No.: RH100

LEDGER LOAD TESTING
Test Method: ANSI/SSFI SC 100-5/05

Uniform Distributed Load

Sample #	Max Load (lbs)	Load at 4:1 Safety Factor (lbs)	% Deviation From Average
1	4,520	1,130	9
2	3,920	980	6
3	4,020	1,010	4
Average	4,150	1,040	---




Distributed Load Test Setup



Typical Deflection at Maximum Load

TRUSS LEDGER

Ringlock Truss Ledger is engineered to enable higher service loads to the working platform. Tube size: OD48.3x3.2mm, Steel Grade:Q235 or Q355. Surface treatment: Hot dip galvanized.




Item No.	Ref. No	Description	Height		Weight		Point Load	Uniform Load
			Meters	Feet	Kgs	Lbs	Lbs	Lbs
RDL50	RL1511	5' Truss Ledger 1524mm	1.52	5'-0"	9.47	20.86	3,300	3,490
RDL52	RL1512	5'-2" Truss Ledger 1570mm	1.57	5'-2"	9.74	21.45	3,160	3,380
RDL60	RL1513	6' Truss Ledger 1828mm	1.82	6'-0"	11.56	25.46	2,690	2,820
RDL70	RL1514	7' Truss Ledger 2130mm	2.13	7'-0"	13.62	30.00	2,200	2,300
RDL80	RL0624	8' Truss Ledger 2440mm	2.43	8'-0"	15.36	33.83	2,000	2,100
RDL86	RL1515	8'6" Truss Ledger 2572mm	2.572	8'-6"	16.47	36.28	1,860	2,000
RDL90	RL1516	9' Truss Ledger 2740mm	2.74	9'-0"	17.43	38.39	1,720	1,750
RDL100	RL1517	10' Truss Ledger 3050mm	3.05	10'-0"	19.53	43.02	1,250	1,270

■ Diagonal Brace / Bay Brace

Bay Brace 6'-6" (2.0m) Lift

The Bay Brace is used for the lateral bracing of Ringlock Scaffold. Tube size:OD48.3X2.5mm, Steel Grade: S235 or S355. Surface treatment: Hot dip galvanized.




Item No.	Ref. No	Description	Height		Weight	
			Meters	Feet	Kgs	Lbs
RBR20	RL0979	2'-0" Bay Brace 609mm	0.60	2'-0"	7.78	17.14
RBR22	RL1044	2'-2" Bay Brace 650mm	0.65	2'-2"	7.81	17.20
RBR210	RL1520	2'-10" Bay Brace 880mm	0.88	2'-10"	8.00	17.62
RBR30	RL0221	3'-0" Bay Brace 910mm	0.91	3'-0"	8.04	17.71
RBVD36	RL0038	3'-6" Bay Brace 1065mm	1.065	3'-6"	8.21	18.08
RBVD310	RL0682	3'-10" Bay Brace 1150mm	1.15	3'-10"	8.31	18.30
RBVD40	RL0060	4'-0" Bay Brace 1220mm	1.22	4'-0"	8.40	18.50
RBVD50	RL0072	5'-0" Bay Brace 1520mm	1.52	5'-0"	8.86	19.52
RBVD52	RL0571	5'-2" Bay Brace 1570mm	1.57	5'-2"	8.95	19.71
RBVD54	RL1033	5'-4" Bay Brace 1625mm	1.625	5'-4"	9.03	19.89
RBVD60	RL0103	6'-0" Bay Brace 1828mm	1.828	6'-0"	9.39	20.68
RBVD70	RL0156	7'-0" Bay Brace 2130mm	2.13	7'-0"	9.98	21.98
RBVD80	RL0160	8'-0" Bay Brace 2440mm	2.44	8'-0"	10.63	24.05
RBVD86	RL1501	8'-6" Bay Brace 2572mm	2.572	8'-6"	10.92	23.41
RBVD90	RL0626	9'-0" Bay Brace 2740mm	2.74	9'-0"	11.30	24.89
RBVD100	RL0109	10'-0" Bay Brace 3050mm	3.05	10'-0"	12.02	26.48

■ Swivel Clamp Brace

Swivel Clamp Brace 6'-6" (2.0m) Lift


The Swivel Clamp Brace gives the user more versatility to attach the brace to any location on the Ringlock verticals. Tube size: OD48.3x3.2mm, Steel Grade: Q235 or Q355. Surface treatment: Hot dip galvanized.



Item No.	Ref. No	Description	Height		Weight	
			Meters	Feet	Kgs	Lbs
RSCB50	RL1521	5'-0" Swivel Clamp Brace 1520mm	1.524	5'-0"	9.43	20.77
RSCB70	RL1468	7'-0" Swivel Clamp Brace 2130mm	2.13	7'-0"	10.61	23.37
RSCB80	RL1522	8'-0" Swivel Clamp Brace 2440mm	2.44	8'-0"	11.28	24.85
RSCB82	RL1496	8'-2" Swivel Clamp Brace 2500mm	2.50	8'-2"	11.41	25.13
RSCB10	RL1469	10'-0" Swivel Clamp Brace 3050mm	3.05	10'-0"	12.70	27.97

Ringlock Side Bracket


The Ringlock Side Bracket is used to extend the working platform closer to the building structure. Steel Grade: Q235 or Q355. Surface treatment: Hot dip galvanized.



Item No.	Ref. No	Description	Height		Weight		Uniform Load
			Meters	Feet	Kgs	Lbs	Lbs
RSB1	RL0642	1' Side Bracket	0.31	1'	1.83	4.03	400
RSB22	RL1523	2'2" Side Bracket	0.65	2'-2"	5.95	13.11	1,000
RSB25	RL1490	2'5" Side Bracket	0.732	2'-5"	6.39	14.07	920
RSB210	RL1524	2'10" Side Bracket	0.88	2'-10"	7.33	16.15	800
RSB3	RL0270	3' Side Bracket	0.914	3'	7.50	16.52	730

Lattice Girder


The Lattice Girder is a horizontal member of Ringlock scaffolding that allows for bridging over large spans of 14'-28'. Steel Grade: Q235 or Q355. Surface treatment: Hot dip galvanized.



Item No.	Ref. No	Description	Height		Weight		Point Load	Uniform Load
			Meters	Feet	Kgs	Lbs		
RSLG10	RL1527	Lattice Girder 10'	3.05	10'	32.30	71.15	5,600	7,035
RSLG14	RL1492	Lattice Girder 14'	4.26	14'	42.90	94.49	3,425	6,580
RSLG16	RL1528	Lattice Girder 16'	4.88	16'	49.20	108.37	3,400	6,310
RSLG17	RL1529	Lattice Girder 17'	5.18	17'	51.40	113.22	3,315	6,020
RSLG21	RL1493	Lattice Girder 21'	6.39	21'	63.90	140.75	1,705	5,380
RSLG28	RL1494	Lattice Girder 28'	8.52	28'	84.90	187.00	1,160	4,335

Steel Plank 9.5" (238mm)

Ringlock Low Profile Steel Plank, Width: 9.5" (238mm), Height: 2.76" (70mm), Thickness: 0.06" (1.5mm). Steel Grade: Q355B High Tensile Strength Steel, Surface treatment: Pre-galvanized (200g/m² zinc thickness).



Item No.	Ref. No	Description	Height		Weight		Point Load	Uniform Load
			Meters	Feet	Kgs	Lbs	Lbs	Lbs/ft ²
RDEP20	WP0449	2' Low Profile Steel Plank	0.61	1'-11"	4.94	10.79	750	75
RDEP22	WP0479	2'-2" Low Profile Steel Plank	0.65	2'-2"	5.15	11.34	750	75
RDEP210	WP0494	2'-10" Low Profile Steel Plank	0.88	2'-9"	6.37	14.03	750	75
RDEP30	WP0446	3' Low Profile Steel Plank	0.914	3'-0"	6.55	14.43	750	75
RDEP36	WP0448	3'-6" Low Profile Steel Plank	1.065	3'-6"	7.35	16.19	750	75
RDEP310	WP0483	3'-10" Low Profile Steel Plank	1.15	3'-10"	7.80	17.18	750	75
RDEP40	WP0465	4' Low Profile Steel Plank	1.22	4'-0"	8.17	18.00	750	75
RDEP50	WP0477	5' Low Profile Steel Plank	1.524	5'-0"	9.78	21.54	750	75
RDEP52	WP0478	5'-2" Low Profile Steel Plank	1.572	5'-2"	10.04	22.11	750	75
RDEP60	WP0463	6' Low Profile Steel Plank	1.829	6'-0"	11.40	25.11	750	75
RDEP70	WP0447	7' Low Profile Steel Plank	2.13	7'-0"	13.00	28.63	750	75
RDEP80	WP0462	8' Low Profile Steel Plank	2.44	8'-0"	14.63	32.22	750	75
RDEP86	WP0487	8'-6" Low Profile Steel Plank	2.572	8'-6"	15.33	33.77	500	50
RDEP100	WP0436	10' Low Profile Steel Plank	3.05	10'-0"	17.87	39.36	500	50



TEST REPORT

No. : SHIN2308001241CM01_EN

Date : 2023-09-01

Page: 5 of 8

2. Test Item: Deflection at Three Person Capacity - 750 Pounds Total

Test Method: ANSI/ASSP A10.8-2019 Section 5.1.2.2.4

Test Condition:

Specimen: 2130mm×238mm×70mm, 1pc

Test span: 2130mm

Test Result:

Test Item	Test Result	Requirement in ANSI/ASSP A10.8-2019 Section 5.1.1.3	Conclusion
Deflection at Three Person Capacity - 750 Pounds Total	14.79 mm	≤35.50 mm <small>Note</small>	Pass

Note: The deflection at the center of the platform unit under design load shall not exceed the span divided by 60

Test Photo(s):





TEST REPORT

No. : SHIN2308001241CM01_EN

Date : 2023-09-01

Page: 4 of 8

1. Test Item: Deflection at Two Person Capacity - 500 Pounds Total

Test Method: ANSI/ASSP A10.8-2019 Section 5.1.2.2.3

Test Condition:

Specimen: 3050mm×238mm×70mm, 1pc

Test span: 3050mm

Test Result:

Test Item	Test Result	Requirement in ANSI/ASSP A10.8-2019 Section 5.1.1.3	Conclusion
Deflection at Two Person Capacity - 500 Pounds Total	17.37 mm	≤50.83 mm <small>Note</small>	Pass

Note: The deflection at the center of the platform unit under design load shall not exceed the span divided by 60

Test Photo(s):





TEST REPORT

No. : SHIN2308001241CM01_EN

Date : 2023-09-01

Page: 7 of 8

4. Test Item: Deflection at Uniformly Distributed Load of 75 Pounds Per Square Foot (Heavy - Duty)

Test Method: ANSI/ASSP A10.8-2019 Section 5.1.2.3.5

Test Condition:

Specimen: 2130mm×238mm×70mm, 1pc

Test span: 2130mm

Test Result:

Test Item	Test Result	Requirement in ANSI/ASSP A10.8-2019 Section 5.1.1.3	Conclusion
Deflection at Uniformly Distributed Load of 75 Pounds Per Square Foot (Heavy - Duty)	6.10 mm	≤35.50 mm <small>Note</small>	Pass

Note: The deflection at the center of the platform unit under design load shall not exceed the span divided by 60

Test Photo(s):





TEST REPORT

No. : SHIN2308001241CM01_EN

Date : 2023-09-01

Page: 6 of 8

3. Test Item: Deflection at Uniformly Distributed Load of 50 Pounds Per Square Foot (Medium - Duty)

Test Method: ANSI/ASSP A10.8-2019 Section 5.1.2.3.4

Test Condition:

Specimen: 3050mm×238mm×70mm, 1pc

Test span: 3050mm

Test Result:

Test Item	Test Result	Requirement in ANSI/ASSP A10.8-2019 Section 5.1.1.3	Conclusion
Deflection at Uniformly Distributed Load of 50 Pounds Per Square Foot (Medium - Duty)	10.44 mm	≤50.83 mm <small>Note</small>	Pass

Note: The deflection at the center of the platform unit under design load shall not exceed the span divided by 60


Test Photo(s):



Steel Plank 9" (228.6mm)

Ringlock Steel Plank, Width: 9" (228.6mm), Height: 2.5" (63.5mm), Thickness: 0.07" (1.8mm).

Steel Grade: Q235B Steel sheet, Surface treatment: Hot dip galvanized.



Item No.	Ref. No	Description	Height		Weight		Point Load	Uniform Load
			Meters	Feet	Kgs	Lbs		
RSSP20	WP0027	2' Steel Plank	0.60	2'	4.78	10.53	820	1,650
RSSP27	WP0028	2'-7" Steel Plank	0.78	2'-7"	5.82	12.82	810	1,600
RSSP210	WP0495	2'-10" Steel Plank	0.88	2'-10"	6.40	14.10	805	1,550
RSSP30	WP0029	3' Steel Plank	0.91	3'	6.55	14.43	800	1,510
RSSP36	WP0030	3'-6" Steel Plank	1.065	3'-6"	7.43	16.37	750	1,420
RSSP4	WP0032	4' Steel Plank	1.22	4'	8.34	18.37	710	1,360
RSSP50	WP0034	5' Steel Plank	1.52	5'	10.11	22.27	640	1,240
RSSP52	WP0041	5'-2" Steel Plank	1.57	5'-2"	10.38	22.86	610	1,130
RSSP60	WP0037	6' Steel Plank	1.82	6'	11.89	26.19	570	1,090
RSSP70	WP0039	7' Steel Plank	2.13	7'	13.64	30.04	510	920
RSSP80	WP0042	8' Steel Plank	2.43	8'	15.45	34.03	470	830
RSSP82	WP0409	8'-2" Steel Plank	2.5	8'-2"	15.70	34.58	420	750
RSSP9	WP0045	9' Steel Plank	2.74	9'	17.21	37.91	390	650
RSSP100	WP0046	10' Steel Plank	3.05	10'	19.00	41.85	340	570



Coronet Scaffold Group Suzhou Co., Ltd.
SIFC SIP, Suzhou City
Jiangsu Province, China
P: +86-512-85557000 / F: +86-512-85557111

Element Materials Technology
222 Cavalcade Street
Houston, TX
77009-3213 USA
P 713 692 9151
F 713 696 6307
T 888 786 7555
info.houston@element.com
element.com

TEST CERTIFICATE – EAR-CONTROLLED DATA


Date: 01/15/2013
P.O. No.: EHO0006255Q/0
W/O No.: COR006-12-12-09684-1

Description: 5' Steel Plank
Part No.: SSP5

STEEL PLANK LOAD TESTING Test Method: ANSI A10.8, ANSI/SSFI SC 100-5/05

POINT LOAD

Test #	Max Load (lbs)	Load at 4:1 Safety Factor (lbs)	% Deviation From Average
1	2,680	670	5
2	2,470	620	3
3	2,470	620	3
Average	2,540	640	---



5' point load setup



Typical 5' point load deflection



Coronet Scaffold Group Suzhou Co., Ltd.
SIFC SIP, Suzhou City
Jiangsu Province, China
P: +86-512-85557000 / F: +86-512-85557111

Element Materials Technology
222 Cavalcade Street
Houston, TX
77009-3213 USA
P 713 692 9151
F 713 696 6307
T 888 786 7555
info.houston@element.com
element.com

TEST CERTIFICATE – EAR-CONTROLLED DATA

Date: 01/15/2013
P.O. No.: EHO0006255Q/0
W/O No.: COR006-12-12-09684-1

Description: 5' Steel Plank
Part No.: SSP5

STEEL PLANK LOAD TESTING

Test Method: ANSI A10.8, ANSI/SSFI SC 100-5/05

UNIFORMLY DISTRIBUTED LOAD

Test #	Max Load (lbs)	Load at 4:1 Safety Factor (lbs)	% Deviation From Average
1	4,820	1,210	3
2	5,030	1,260	1
3	5,030	1,260	1
Average	4,960	1,240	---



5' UDL setup



Typical 5' UDL deflection



Coronet Scaffold Group Suzhou Co., Ltd.
SIFC SIP, Suzhou City
Jiangsu Province, China
P: +86-512-85557000 / F: +86-512-85557111

Element Materials Technology
222 Cavalcade Street
Houston, TX
77009-3213 USA
P 713 692 9151
F 713 696 6307
T 888 786 7555
info.houston@element.com
element.com

TEST CERTIFICATE – EAR-CONTROLLED DATA

Date: 01/15/2013
P.O. No.: EHO0006255Q/0
W/O No.: COR006-12-12-09684-1

Description: 7' Steel Plank
Part No.: SSP7

STEEL PLANK LOAD TESTING
Test Method: ANSI A10.8, ANSI/SSFI SC 100-5/05**POINT LOAD**

Test #	Max Load (lbs)	Load at 4:1 Safety Factor (lbs)	% Deviation From Average
1	2,060	520	2
2	2,060	520	2
3	1,950	490	4
Average	2,020	510	---



7' point load setup



Typical 7' point load deflection



Coronet Scaffold Group Suzhou Co., Ltd.
SIFC SIP, Suzhou City
Jiangsu Province, China
P: +86-512-85557000 / F: +86-512-85557111

Element Materials Technology
222 Cavalcade Street
Houston, TX
77009-3213 USA
P 713 692 9151
F 713 696 6307
T 888 786 7555
info.houston@element.com
element.com

TEST CERTIFICATE – EAR-CONTROLLED DATA

Date: 01/15/2013
P.O. No.: EHO0006255Q/0
W/O No.: COR006-12-12-09684-1

Description: 7' Steel Plank
Part No.: SSP7

STEEL PLANK LOAD TESTING
Test Method: ANSI A10.8, ANSI/SSFI SC 100-5/05

UNIFORMLY DISTRIBUTED LOAD

Test #	Max Load (lbs)	Load at 4:1 Safety Factor (lbs)	% Deviation From Average
1	3,520	880	5
2	3,770	940	2
3	3,770	940	2
Average	3,680	920	---



7' UDL setup



Typical 7' UDL deflection



Coronet Scaffold Group Suzhou Co., Ltd.
SIFC SIP, Suzhou City
Jiangsu Province, China
P: +86-512-85557000 / F: +86-512-85557111

Element Materials Technology
222 Cavalcade Street
Houston, TX
77009-3213 USA
P 713 692 9151
F 713 696 6307
T 888 786 7555
info.houston@element.com
element.com

TEST CERTIFICATE – EAR-CONTROLLED DATA

Date: 01/15/2013
P.O. No.: EHO0006255Q/0
W/O No.: COR006-12-12-09684-1

Description: 10' Steel Plank
Part No.: SSP10

STEEL PLANK LOAD TESTING

Test Method: ANSI A10.8, ANSI/SSFI SC 100-5/05

POINT LOAD

Test #	Max Load (lbs)	Load at 4:1 Safety Factor (lbs)	% Deviation From Average
1	1,340	340	0
2	1,340	340	0
3	1,340	340	0
Average	1,340	340	---



10' point load setup



Typical 10' point load deflection



Coronet Scaffold Group Suzhou Co., Ltd.
SIFC SIP, Suzhou City
Jiangsu Province, China
P: +86-512-85557000 / F: +86-512-85557111

Element Materials Technology
222 Cavalcade Street
Houston, TX
77009-3213 USA
P 713 692 9151
F 713 696 6307
T 888 786 7555
info.houston@element.com
element.com

TEST CERTIFICATE – EAR-CONTROLLED DATA

Date: 01/15/2013
P.O. No.: EHO0006255Q/0
W/O No.: COR006-12-12-09684-1

Description: 10' Steel Plank
Part No.: SSP10

STEEL PLANK LOAD TESTING

Test Method: ANSI A10.8, ANSI/SSFI SC 100-5/05

UNIFORMLY DISTRIBUTED LOAD

Test #	Max Load (lbs)	Load at 4:1 Safety Factor (lbs)	% Deviation From Average
1	2,310	580	1
2	2,310	580	1
3	2,210	550	3
Average	2,280	570	---




10' UDL setup



Typical 10' UDL deflection

Base Collar


Ringlock Steel Plank, Width: 9" (228.6mm), Height: 2.5" (63.5mm), Thickness: 0.07" (1.8mm).
 Steel Grade: Q235B Steel sheet, Surface treatment: Hot dip galvanized.



Item No.	Ref. No	Description	Height		Weight	
			Meters	Feet	Kgs	Lbs
RSBC	RL0248	Starter/Base Collar	0.3	1'-0"	1.8	3.96

Adjustable Base Jack

Ringlock adjustable base jack is used for leveling the scaffold-standards at the same height. OD: 38.1x4.5mm. Base plate: 150x150x6mm. Surface treatment: Hot dip galvanized.



Item No.	Ref. No	Description	Height		Weight	
			Meters	Feet	Kgs	Lbs
CSJB	AS0020	24" Adjustable Base Jack	0.6	2'	3.4	7.49
Item No.	Ref. No	Description	Height		Allowable Load	
			Meters	Feet	Lbs	
CSJB	AS0020	24" Adjustable Base Jack	0.152	6"	12,370	
			0.305	12"	10,020	
			0.457	18"	9,940	



Coronet Scaffold Group Suzhou Co., Ltd.
SIFC SIP, Suzhou City
Jiangsu Province, China
P: +86-512-85557000 / F: +86-512-85557111

Element Materials Technology
222 Cavalcade Street
Houston, TX
77009-3213 USA
P 713 692 9151
F 713 696 6307
T 888 786 7555
info.houston@element.com
element.com

TEST CERTIFICATE – EAR-CONTROLLED DATA

Date: 01/15/2013
P.O. No.: EHO0006255Q/0
W/O No.: COR006-12-12-09684-2

Description: Hollow Screw Jacks
Part No.: SJB

LOAD TEST RESULTS

Test Method: ANSI/SSFI SC100-5/05

Sample #	Extension (in.)	Max Load (lbs)	Load at 4:1 Safety Factor (lbs)	% Deviation from Average
1	6	48,100	12,025	3
2	6	48,800	12,200	1
3	6	51,500	12,875	4
Average	---	49,470	12,370	---



6" extension setup



6" typical deflection



Coronet Scaffold Group Suzhou Co., Ltd.
SIFC SIP, Suzhou City
Jiangsu Province, China
P: +86-512-85557000 / F: +86-512-85557111

Element Materials Technology
222 Cavalcade Street
Houston, TX
77009-3213 USA
P 713 692 9151
F 713 696 6307
T 888 786 7555
info.houston@element.com
element.com

TEST CERTIFICATE – EAR-CONTROLLED DATA

Date: 01/15/2013
P.O. No.: EHO0006255Q/0
W/O No.: COR006-12-12-09684-2

Description: Hollow Screw Jacks
Part No.: SJB

LOAD TEST RESULTS

Test Method: ANSI/SSFI SC100-5/05

Sample #	Extension (in.)	Max Load (lbs)	Load at 4:1 Safety Factor (lbs)	% Deviation from Average
1	12	44,310	11,080	9
2	12	38,240	9,560	6
3	12	37,710	9,430	7
4	12	42,130	10,530	4
Average	---	40,600	10,020	---





Coronet Scaffold Group Suzhou Co., Ltd.
SIFC SIP, Suzhou City
Jiangsu Province, China
P: +86-512-85557000 / F: +86-512-85557111

Element Materials Technology
222 Cavalcade Street
Houston, TX
77009-3213 USA
P 713 692 9151
F 713 696 6307
T 888 786 7555
info.houston@element.com
element.com

TEST CERTIFICATE – EAR-CONTROLLED DATA

Date: 01/15/2013
P.O. No.: EHO0006255Q/0
W/O No.: COR006-12-12-09684-2

Description: Hollow Screw Jacks
Part No.: SJB

LOAD TEST RESULTS


Test Method: ANSI/SSFI SC100-5/05

Sample #	Extension (in.)	Max Load (lbs)	Load at 4:1 Safety Factor (lbs)	% Deviation from Average
1	18	41,650	10,710	5
2	18	39,220	9,805	1
3	18	38,440	9,610	3
Average	---	39,770	9,940	---



■ Swivel Base Jack


The swivel base jack can be used when standards need to be placed on slopes. OD: 38.1x4.5mm.
Base plate: 150x150x6mm. Surface treatment: Hot dip galvanized or Electroplated.



Item No.	Ref. No	Description	Height		Weight	
			Meters	Feet	Kgs	Lbs
CSJS	AS0021	24" Swivel Base Jack	0.6	2'	3.7	8.15

Guardrail Post


The Guardrail Post is designed to provide a vertical connection to secure Ledger. Surface treatment: Hot dip galvanized.




Item No.	Ref. No	Description	Height		Weight	
			Meters	Feet	Kgs	Lbs
RGP	RL0100	1.7M Guardrail Post	1.7	5'-6"	8.7	19.16

Safety Gate

The safety gate allows safe access to the working platform. The spring gate mechanism ensures that the access opening remains fully closed when the scaffold is in use.







Item No.	Ref. No	Description	Min Extension		Max Extension	
			Meters	Inches	Meters	Inches
RCW	AS0224	3'~5' Swing Gate	0.61	36.00	1.52	60.00
RCWL	RL0016	Gate Expandable Safety Gate 35" to 56"	0.89	34.65	1.42	56.00

■ Stair Stringer & Tread

Ringlock Staircase tower incorporate purpose designed stairway unites and offer a safer, quicker,more efficient route between levels on site. The stair tread is designed as the horizontal member connecting to the stair stringers (both 1.0m and 2.0m lift) providing the steps of the stair system.






Item No.	Ref. No	Description	Height		Weight	
			Meters	Feet	Kgs	Lbs
RSS213	RL0328	7' Stair Stringer(2.0m lift)	2.13	7'	15.50	34.14
RST850	RL1443	32" Stair Tread-305mm Steel Board	0.857	32"	8.50	18.72
RST810	RL0250	32" Stair Tread-262mm Steel Board	0.857	32"	7.10	16.54

■ Interlocking Toeboard


The Interlocking Toeboard is designed as the horizontal member connecting to provide a protection for scaffolding tools.



Item No.	Ref. No	Description	Height		Weight	
			Meters	Feet	Kgs	Lbs
RSITB22	WP0435	2'-2" Interlocking Toeboard	0.65	2'-2"	2.12	4.67
RSITB210	WP0496	2'-10" Interlocking Toeboard	0.88	2'-10"	2.77	6.10
RSITB30	WP0497	3' Interlocking Toeboard	0.91	3'-0"	2.86	6.30
RSITB36	WP0498	3'-6" Interlocking Toeboard	1.065	3'-6"	3.29	7.25
RSITB310	WP0434	3'-10" Interlocking Toeboard	1.15	3'-10"	3.52	7.75
RSITB50	WP0499	5' Interlocking Toeboard	1.52	5'-0"	4.57	10.07
RSITB52	WP0433	5'-2" Interlocking Toeboard	1.57	5'-2"	4.71	10.37
RSITB60	WP0500	6' Interlocking Toeboard	1.82	6'-0"	5.43	11.96
RSITB70	WP0432	7' Interlocking Toeboard	2.13	7'-0"	6.27	13.81
RSITB80	WP0501	8' Interlocking Toeboard	2.43	8'-0"	7.14	15.73
RSITB10	WP0431	10' Interlocking Toeboard	3.05	10'-0"	8.84	19.47

Non-Slip Steel Ladder


The Non-Slip Steel Ladder is designed to attach (using Ladder Brackets) on the inside or outside of a scaffold to provide safe access to the various deck levels. Width: 13-2/3"(347mm).



Item No.	Ref. No	Description	Height		Weight	
			Meters	Feet	Kgs	Lbs
RSAL03	RL1497	3' Non-Slip Steel Ladder	0.91	3'	6.81	15.00
RSAL05	RL1498	5' Non-Slip Steel Ladder	1.52	5'	9.74	21.45
RSAL10	RL1499	10' Non-Slip Steel Ladder	3.05	10'	18.54	40.84

Ladder Bracket


The Ladder Bracket is designed to attach the ladders to the vertical or horizontal members of the scaffold tower.



Item No.	Ref. No.	Description	Height		Weight	
			Meters	Feet	Kgs	Lbs
RSALB	RL1500	Ladder Bracket	0.347	13-2/3"	3.70	8.15

Adjustable Caster Adapter


Caster Adapter is mainly used for connecting caster wheel to the vertical pole.



Item No.	Ref. No	Description	Height		Weight	
			Meters	Feet	Kgs	Lbs
RACA	RL0119	Adjustable Caster Adapter	0.315	12.40"	3.70	8.15

Caster Wheel


Scaffolding Caster Wheel is used at bottom of scaffolding vertical tube, enabling the scaffolding system to be a mobile Platform.



Item No.	Ref. No	Description	Height		Weight	
			Meters	Feet	Kgs	Lbs
CW12	RL0118	12" Caster Wheel	0.3	12"	19.00	41.85

■ Spigot Adapter Clamp (I-Bolt)


The Spigot Adapter Clamp (I-Bolt) allows the connection of Ringlock Standards at intermediate locations along the length of Ledgers, Truss Ledgers and Girders.



Item No.	Ref. No	Description	Weight	
			Kgs	Lbs
RSC	RL0956	Spigot Adapter Clamp (I-Bolt)	1.72	3.79

■ Wedge Head Coupler


Wedge Head Coupler allows the connection of ringlock standards to enforce its strength.



Item No.	Ref. No	Description	Weight	
			Kgs	Lbs
WHC	RL1314	Wedge Head Coupler	1.32	2.91

Right Angle Adapter Clamp


The Right Angle Wedge Head Clamp is designed to easily join a scaffold tube directly to the rosette at 90 degrees.



Item No.	Ref. No	Description	Weight	
			Kgs	Lbs
RwR	RL1110	Right Angle Adapter Clamp	1.59	3.50

■ Swivel Adapter Clamp


The Swivel Adapter Clamp is designed to easily join a scaffold tube to the rosette of a Ringlock scaffold producing a variety of angles and configurations.



Item No.	Ref. No	Description	Weight	
			Kgs	Lbs
RWS	RL1530	Swivel Adapter Clamp	1.61	3.55

■ Rosette Clamp

The Rosette Clamp is used to add a rosette at any point on a vertical standard or tube.



Item No.	Ref. No	Description	Weight	
			Kgs	Lbs
RRC	TC0211	Rosette Clamp	1.2	2.64

■ Right Angle Clamp (I-Bolt)

The Right Angle Clamp (I-Bolt) is designed to be used in conjunction with scaffold tube to create 90 degree angles.



Item No.	Ref. No	Description	Weight	
			Kgs	Lbs
RCA	TC0020	Right Angle Clamp	1.50	3.30

■ Swivel Clamp (I-Bolt)

The Swivel Clamp (I-Bolt) is designed to be used in conjunction with scaffold tube to create a variety of angles.



Item No.	Ref. No	Description	Weight	
			Kgs	Lbs
RCS	TC0021	Swivel Clamp	1.80	3.96

■ Swivel Clamp (I-Bolt)

The Swivel Clamp (I-Bolt) is designed to be used in conjunction with scaffold tube to create a variety of angles.



Item No.	Ref. No	Description	Weight	
			Kgs	Lbs
BC	TC0059	Beam Clamp	1.45	3.19

■ Swivel Clamp (I-Bolt)


The Swivel Clamp (I-Bolt) is designed to be used in conjunction with scaffold tube to create a variety of angles.



Item No.	Ref. No	Description	Weight	
			Kgs	Lbs
SBC	TC0177	Swivel Beam Clamp	1.80	3.96

Scaffold Rack

The Scaffold Rack is designed to load scaffolding components for transportation.



Item No.	Ref. No	Description	Weight	
			Kgs	Lbs
CSR	AS0180	Scaffold Rack 42" X 42" X 34.25"	46	101.32

Scaffold Rack


The Scaffold Rack is designed to load scaffolding components for transportation.



Item No.	Ref. No	Description	Weight	
			Kgs	Lbs
CSBR	AS0203	Scaffold Basket Rack 42" X 42" X 34.25"	60	132.16

Scaffold Cage Insert

The Scaffold Cage insert is designed to fit into the storage rack, to create the basket for storage of clamps and accessories.



Item No.	Ref. No	Description	Weight	
			Kgs	Lbs
CSCI	AS0384	Scaffold Cage Insert 40" X 40" X 33"	23.45	51.65



5. SECURITY INSTRUCTIONS



Safety considerations

This guide and all the handling procedures detailed in it are intended for everyone who works with the Coronet ringlock system. It contains information on standard configurations of the system and on its correct use according to the principles established by the UNE EN 12810 and UNE EN 12811 standards.

- The property and/or the optional addresses of the construction sites and premises where the system is used must ensure that all technical documents are available to all users of the scaffolding.
- In all cases, users are obliged to comply with national legislation, standards and regulations throughout the project and take additional or alternative workplace safety precautions, where necessary.
- This document may serve as a basis, support or complement at the time of writing, by the company responsible for the work or client, of the risk assessment or safety plan necessary in each of the works where it is going to be carried out. use the Coronet ringlock scaffolding system. In addition, it may be used for instructions provided to users on how to set up and use the system. However, it will never replace the indications reflected in the aforementioned documents related to safety and health in construction sites.
- If at any time the possibility of modifying the instructions, steps, advice or simply part of these, described in this guide for the assembly of the system, is foreseen or studied, new revised static calculations must be carried out for their verification, as well as instructions for complementary assembly.

Failure to follow the instructions, technical data, warnings, data on loads and other advice for the correct use of the system can lead to or cause serious accidents and significant material and personal damage.

- If the weather conditions during the assembly of the system are adverse, such as strong winds, rain or frost, the work must be stopped or in any case the steps must be carried out with an adequate rhythm in order to safeguard the equipment and the adjacent areas of the equipment and protect the operators.
- The installation of the system, once assembled and in use, must be constantly reviewed by the operators or by personnel responsible for the assembly guarantee, certifying at all times the correct arrangement of all the joints, fixings, parts and components that the system has.

■ Safety procedure prior assembly

To handle scaffolding, it is important to take into account the safety procedure during all the assembly steps.

Safety equipment

All the people dedicated to the assembly and disassembly of scaffolding must have and will be obliged to use the individual protection elements that are observed in the following image.



SUGGESTIONS:

Prior to the assembly and use of the scaffolding, the following recommendations must be followed :

- Inspect all components.
- Analyze the requirements that are demanded for work at height before starting the project.
- Prepare all the protection equipment and safety elements, hammer and spirit level.
- Mark the work area with a warning notice in order to avoid accidents.
- Make sure of your position and balance before releasing the equipment. Always have one hand on the ladder or a support element.
- SUSPEND work on the scaffolding during strong winds, rain and other inclement weather conditions.r .

USE OF THE HARNESS:

If you work with a safety harness, you need to have a height rescue plan at the construction site
The harness fixing system can be made in the following elements:

- Ledger: at the point of highest available height. Both ends must be anchored
- Standard: anywhere on the standard, including the rosette



NOTES:

The connection points :

- They must respect the laws of each country / region;
- They will be carried out as high as possible above the actual work floor (minimum height of 1 meter from the work platform).

Connect the carabiner hook to the safety harness to the closed parts of the scaffold that prevent the hook from slipping.

Initial inspection

The elements that denote a technical failure or a bad structural behavior will be dismantled immediately, proceeding to its repair or replacement.

In addition, assembly tools or protective equipment that are defective must be replaced by others. Those parts of the scaffolding that are not ready for use, mainly during assembly and disassembly, must be marked and conveniently delimited by means of physical elements that prevent access to the danger zone.

Check all loads imposed on the scaffold erection and its surroundings, and ensure the position of the loads on the scaffold and its surroundings. The various loads are:

- Weight of scaffold structure
- Workload of the work platform
- Wind load.

Check the condition of the ground scaffold and the elevation condition of the anchor point:

- Understand all safety regulations (local)
- Understanding the potential risks of an explosion or fire

Check the training of workers.

Correct repositioning is essential for safety work and must always be done in accordance with assembly drawings or technical personnel instructions. Check that the ground is strong and flat without any uneven or easily deformed for placement of bruski or pillows.



6. ASSEMBLY PROCESS




■ Standard assembly procedure for facade scaffold

STEP 1

Prepare the foundation for the scaffold.

The base collars and base Jacks are placed on a flat surface to distribute the pressure exerted by the scaffolding on the ground. Place the base jack or base collar (optional) to serve as support for the standard of the ringlock scaffolding and to facilitate the placement of the ledger and diagonal brace.




STEP 2

Connect the Ledgers

Connect the Ledgers head to the little hole position of the rosette on the Base Collar, making a angle of 90° between ledgers. In order to ensure the ledgers are horizontal, use a spirit level to adjust the base jack if necessary. Also check the distance from the scaffolding to the facade.


IMPORTANT: When installing platforms, they must be protected with safety equipment.



STEP 3


Place the Standard

The bottom of the Standards fit into the socket tube at the top of the Base Collar. The Spigot on the Standards always point upwards.




STEP 4**Place the Ledgers and Diagonal Brace**

The ledger is placed at the maximum distance of 2 meters from the previous level. The diagonal brace along the entire standard of the scaffolding and every 4 rosette as standard. Tighten the wedges to ensure the definitive rigidity of the structure.

**STEP 5****Place the platform and access platform**


Non-slip platforms are placed on the crossbars to form a work surface with a minimum width of 60 cm.

Important: when installing the platforms, they must be secured with the security equipment.

**STEP 6****Place the Guardrail**


Guardrail should be installed at a height of 0.5m and 1.0m in relation to the work platform in order to guarantee safety against falls from height.

Important: Before starting to climb and assemble the upper levels, the scaffolding must be tied to the structure to the vertical wall.




STEP 7**Place the Toe Board**

Add the toe boards which slot behind the wedge to protect falling objects.

**STEP 8****Assembly the upper level**

The process for the assembly of the upper levels is the same. The assembly is then resumed from point 5 to point 7 of this assembly manual.



Disassembly and storage of the system:



The disassembly and storage of the Coronet ringlock system must be carried out by professional operators and always in the reverse order of assembly.




Items should NEVER be dropped from the top of the scaffold.



The scaffold must be signaled not to use and always use individual protection equipment during dismantling.

STANDARD ASSEMBLY PROCEDURE FOR SCAFFOLD TOWERS



■ Standard Assembly process of volume scaffolding


STEP 1

Place the Base Collars over the Base Jacks (If necessary). Use wooden sole plates boards as necessary depending on the ground conditions.




STEP 2

Assemble the Ledgers and make sure this setup is level.




STEP 3

Thread the vertical standards onto the base collars (Preferably 3 meters).




STEP 4


Assemble the 2nd level structure: bridging Ledger (1.57 meters wide) to support the platform and diagonal brace. Also assemble the Braces on the two outer sides.

**STEP 5**


Assemble the 1st landing including the access platforms, steel planks and toe boards. Repeat the sequence until the desired level is reached. Use the wall tie if the scaffold tower is not stable.



Assemble the 1.0m standard and guardrail on the landing.




STANDARD ASSEMBLY PROCEDURE FOR ACCESS STAIR




STEP 1


Place the Base Collars over the Base Jacks (If necessary). Use wooden sole plates boards as necessary depending on the ground conditions.

**STEP 2**


Assemble the Ledgers and make sure this setup is level. Also Assemble steel plank.

**STEP 3**

Thread the vertical standards onto the base collars (Preferably 3 meters).


**STEP 4**

Place 2nd level ledger and diagonal brace and place the first level of access stair.




STEP 5


Place the 2nd level Standards.

**STEP 6**

Assemble the 1st level internal and external handrail along the stair, as well as place safety guardrails along the next landing.


**STEP 7**

Assemble the 2nd level: place standards, ledgers and diagonal braces. (Use the Scaffold Step to assemble a temporary platform and single advanced Guardrail such that this can be used to erect the second landing).




STEP 8

Assemble the 2nd access stair.


**STEP 9**

Assemble 2nd level safety elements: guardrails at 0.50 & 1.00 meters and external & internal handrails along the stairs.

For the assembly of the upper levels repeat the sequence from step 6.

**STEP 10**


Assemble the last level steel planks and guardrail.



STEP 11

Assemble toe boards if necessary. Then install horizontal fall protection

- 1.0m standard+ tube +clamp
- 1.0 m standard I + ledger



Safe-stable scaffolding

Scaffold structures that are used as mobile or fixed scaffold towers are subjected to the same loads as any other type of scaffold. For towers made of steel without any type of cover, an indicative method to prove that it is self-stable is the following:


The maximum height (H) can not exceed four times the minimum side (L) in an indoor space without wind. - $H \text{ (max)} \leq 4 \times L \text{ (smaller)}$.

The maximum height (H) is three times the minimum side (L) in outdoor space - $H \text{ (max)} \leq 3 \times L \text{ (minimum)}$.

If this standard can not be met due to working conditions :

- Increase the size of the base by placing stabilizers.
- Installation of counterweight.
- Secure the scaffold to a solid structure.


STANDARD ASSEMBLY PROCEDURE FOR SCAFFOLD TOWERS



■ Standard for the use of cranes in scaffolding

To secure the base grader, you must

- The leveler fixer
- Pin.
- Use safety pin locking strut



■ Standard Assembly process of volume scaffolding

STEP 1

Prepare the foundation for the scaffold


The base collars and base Jacks are placed on a flat surface to distribute the pressure exerted by the scaffolding on the ground. Place the base jack or base collar (optional) to serve as support for the standard of the ringlock scaffolding and to facilitate the placement of the ledger and diagonal brace.



STEP 2

Assemble the foundation


Assemble the ledger of the first level.



STEP 3

Assemble Standard and platform


The bottom of the Standards fit into the socket tube at the top of the Base Collar. Place Planks of the correct bay length into the end bay to fully deck out the bay.



STEP 4


Assemble ledgers and diagonal brace

Assemble the 1st level ledgers (at 2 m. height). Optionally, the protection ledgers can also be installed at a level of 1 m height.




STEP 5**Assemble planks and access platform**


Remove low level auxiliary platform and place the platform on the height of 2.0m. Assemble the access platform.

**STEP 6****Assemble horizontal guardrails**

Assemble the horizontal guardrail. These can be removed when upper levels are assembled.

**STEP 7****Assemble the upper levels**

Place a bridging ledger to replace the ledgers as support for the platforms (spans greater than 1.50 meters).



STEP 8**Assemble toe boards**

For the assembly of the upper levels the process is the same. The assembly is then resumed from step 5 to step 7 of this assembly manual.



Standard Assembly process of volume scaffolding

The main purpose of our Coronet Ringlock Scaffolding system is to create work platforms, where the operators who are going to use it can carry out the necessary tasks with total confidence, stability and rigidity, so when the work is being carried out at height, is not a decrease in the quality and execution time of the same.

The work surfaces that we define are created by joining steel or aluminum and wood platforms, in combination with protection elements such as side bars and skirting boards, all supported and fastened to the tubular bearing structure of our Coronet system.

According to the European standard for facade scaffolding (EN12811-1), the minimum width of the work platform must be:

- Class W06 minimum width. =0.60 m
- Class W09 minimum width. =0.90 m
- Class W12 minimum width. =1.20 m

The following outlines how each scaffold structure must be designed, constructed, and maintained to ensure that it will not collapse or shift unintentionally and can be used safely. This applies to all stages of use, including assembly, modification, and even complete disassembly.

Scaffold components must be designed to be transported, installed, used, maintained, dismantled and stored safely.

The structure in use must have a support or foundation capable of resisting the required loads and movement limitations.

The lateral stability of the scaffolding structure, as a whole and punctually, must be verified when it is subjected to the different possible forces, such as wind.

To cover the different working conditions, the EN 12811-1 standard specifies different load classes and work areas. The service classes of our Coronet Ringlock system are arranged in the following table:

Load Class	Uniformly Distributed Load	Concentrated load on a surface of 500mmx500mm	Concentrated load on a surface of 200mmx200mm	Load on a partial surface	
				KN/m ²	Partial Surface.
1	0,75	1,50	1,00	N/A	N/A
2	1,50	1,50	1,00	N/A	N/A
3	2,00	1,50	1,00	N/A	N/A
4	3,00	3,00	1,00	5,00	0,4
5	4,50	3,00	1,00	7,50	0,4
6	6,00	3,00	1,00	10,00	0,5

Depending on the study and dimension of these loads, we must take into account the study of the possible actions that influence the calculation of our load.

7. ANCHORING AND DIAGONAL BRACE

The anchor of our system are the connection points that we make of it to the facade. Its function is to guarantee the immobility of the scaffolding, even in adverse conditions caused by strong winds or great efforts of a different nature.

In general, the anchors or fixings support horizontal loads parallel and perpendicular to the facade.

It is essential to check the solidity of each fixing point of the facade, since a scaffolding, due to the fact that it is the union of several loose components, is a "weak" system and therefore, to create a solid and stable construction, it is necessary to stabilize the scaffold with additional components.

In general, the fixings must be placed one for every 24m² on uncovered scaffolding or one for every 12m² on net scaffolding.

The anchor to stabilize our Coronet Ringlock System must be executed, whenever possible, perpendicular to the facade to be covered and using a connection point that will be attached to each row of studs in our system.


The connection points or anchoring systems used are made up of a special anchoring tubular profile that has a system at one of its ends to be able to embed it on site in the facade (chemical plug, anchor bolt, etc.) or simply a special hook that makes the tube can be fixed to a bolt or eye bolt that we have previously embedded in our facade and on the other hand we have the clamps or staples that fix the anchor tube to the vertical tubular profiles of the scaffolding.

As we have indicated previously, the fixings must be placed one for every 24m² in uncovered scaffolding or one for every 12m² in net scaffolding, but for a correct design the number of them must be determined by calculations or fixed according to a standard configuration, and they should always be placed in a regular pattern throughout the scaffold.

4 TYPES OF BASIC PATTERNS ARE GENERALLY USED:


TIPO 1-1/6 m²

1 fijación en cada nudo.




TIPO 2-1/12 m²

1 fijación en cada nudo. cada m. de altura.




TIPO 3-1/12 m²

fijaciones alternadas cada 2 módulos y cada 4 m. de altura




TIPO 4-1/24 m²


1 fijación alternada cada 2 módulos y cada 8 m. en altura



However, below are possible variants that we can find on site during the installation of our system and its fixing elements:



Fixing to window or balcony



Column fixing







Plate fixing



Facade fixing



Strut fixing 1



Strut fixing 2

The other fundamental part when it comes to guaranteeing the stability offered by the Coronet Ringlock system is the bracing system carried out by means of the diagonal brace.

The diagonal brace has three main functions :

- **Stability** - Supporting much of the effort (in terms of weight);
- **Counter wind** - Guaranteeing the rigidity of the structure even with strong winds;
- **Geometry** - Avoiding the deformation of the geometric configuration of the scaffolding.

We must also emphasize that, as support for the diagonals, the actions carried out by the platforms for stability in the horizontal plane are very important.

However, in the vertical plane, the rigidity of the scaffolding is supplanted by the joint action of the diagonals and the crossbars (or the railings, as necessary).

The number of steps or sections of scaffolding without diagonals will be studied according to the specific work to be carried out, recommending, however, not to leave more than 3 sections without bracing as a minimum.






8.TYPICAL SOLUTIONS




Below, we offer various examples or solutions that can be achieved with our Coronet Ringlock system, according to its different combinations or mounting methods:


Union exterior a 90°(1)




Union exterior a 90°(2)




Union interior a 90°(1)




Union interior a 90°(2)






Union interior a 90°(3)



Union interior a 90°(4)



Facade leveling with a 2 meters drop**Solution for facade with highlight
And use of step beam****Facade with step beam**



9. MAINTENANCE

■ Inspection, care and maintenance

- Scaffolding components must be handled with care during transportation and use, to avoid damage.
- All components must be checked for damage prior to use and assembly.
- The correct operation of all moving components and the existence of contaminants must be supervised.
- Damaged components must be replaced and returned to the manufacturer for repair or destruction.

General inspection and maintenance criteria:

01	The uprights, horizontals, diagonals, horizontals, steel decks, side supports may not show visible damage such as scuffs, cracks and dents; tubes must be visibly straight.
02	Tube-to-diagonal contact areas, bottom and bottom of rosettes, must be flat and free of contaminants (to ensure proper use of horizontals and diagonals). The diagonal must be visibly straight. The spigot should sit straight and tight without play inside the down tube.
03	The components of the scaffold can not be rusty.
04	Tubes/shafts must be visibly straight (deflection < l/300).
05	The adjustable nut on the plates must be undamaged and must rotate freely through the full length of the thread from the bottom to the stop position. The threaded axles of the platforms must not show any damage, such as wear, cracks or dents. The plate (base) must be visibly flat and flush with the plumb on a flat surface.
06	The welds of the verticals, horizontals, platforms, horizontals, among other components, cannot have cracks.
07	Wedges must be able to move freely and be fixed to prevent displacement; wedges must not be bent or cracked.
08	The steel deck must be visibly straight and must rest flat on the horizontals with its reinforcing hooks. Reinforcing hooks must not be bent or cracked. Anti-lift devices must be in place and operational.
09	Scaffold components must be cleaned regularly to prevent the presence of concrete or other contaminants.



10.APPLICABLE REGULATIONS



■ Current legislation and applicable regulations

Coronet RingLock Scaffold System holds the Australia Registration, DITUC Certification in Chile and the Bureau Veritas Certification in Columbia. Also meets the the requirements of ANSI/SSFI SC100-5/05 approved by Element Materials Technology, the best and most reliable materials and products testing laboratory in the US.

International Certifications:

Item	Testing Laboratory	Testing Standard	Year
01	Sandberg in UK	EN12811	2007
02	Element in USA	ANSI/SSFI	2013
03	INTI in Argentina	UNE EN12811	2014
04	MTS in Australia	AS/NZS 1576 &AS/NZS 1577	2015
05	Escuela Colombiana De Ingenieria Julio Garavito	NTC	2017
06	Dictuc in Chile	NCH2501	2020
07	SGS Shanghai	EN12811	2020

■ Disclaimer

While Coronet and all its facilities have taken every reasonable effort to ensure the information contained within this publication is correct and complete and the time of printing, you should be aware that there will be periodical changes and Coronet does not accept any liability for any inconvenience, loss or damage caused as a result of any inaccuracy or omission within this publication.

Changes are periodically made to the information herein, and Coronet reserves the right to make improvements or changes to the content of this document at any time without notice.

Copyright ©2022 Coronet Group. All Rights Reserved. Coronet@coronet-scaffold.com



RINGLOCK SYSTEM

North America



CHINA

5 Xinghan Street, Suzhou, Jiangsu 215021

USA

HOUSTON, TX: 1133 East Airtex Drive Houston, TX 77073

Tel: +1-504-432-1124 Jose Chaumont

CHILE

Tel: +56 978 082717 Bernardo Gutiérrez

EMAIL

coronet@coronet-scaffold.com

WEB

www.scaffolding.com / www.coronet-scaffold.com